











787EX-E(F) (NPR)

| NO. | Parts List | Q'ty |
|-----|---|------|
| ① |  | X1 |
| ② |  | X1 |
| ③ |  | X1 |
| ④ |  | X1 |
| ⑤ |  | X1 |
| ⑥ |  M8X16 | X3 |

| | | |
|---|---|--|
| <p>1</p>  | <p>2</p>  <p>After assembling the mechanism, please pull the knob "A" and then push the mechanism to the correct position.</p> | <p>3</p>  <p>4</p>  |
|---|---|--|